

# TECHNICAL SPECIFICATION



## Baseworker™ 4-Point Chinstrap

AHV220-000-000 Baseworker™ 4-Point Chinstrap / AHV220-000-000



### DESCRIPTION

The new Baseworker™ 4-point chinstrap is fully compatible with JSP® EVO® helmets. On-the-head adjustment makes it easy to find the perfect fit, enhancing comfort and keeping the helmet secure.

### OPTIONS

**AHV220-000-000 Baseworker™ 4-Point Chinstrap  
(AHV220-000-000)**

### SAFETY STANDARDS

EN 397 • ANSI/ISEA Z89.1 Type I

JSP Limited, Worsham Mill, Minster Lovell, Oxford OX29 0TA, England.

Tel: +44 (0)1993 826050 / Fax: +44 (0)1993 824411 / Email: sales@jpsafety.com / Web: www.jpsafety.com

Do Not Publish without written permission from JSP Limited. Contact copyright@jpsafety.com. Information correct in the United Kingdom at date of issue and may be subject to change. Any third-party machine and automated translations processed by users may have inaccuracies and should not be relied upon.

Page 1 of 2 / Issued 20 Feb 2026 / Copyright 2018 - 2026. JSP Limited. All Rights Reserved.



## SPECIFICATIONS



Type  
Baseworker™ Harness

Adjustable  
Fully at 4 individual points



Product Weight  
39.6g



4-pt Chinstrap  
Designed to break when submitted to a force between 150N and 250N

Material  
16mm Woven Nylon Webbing and Nylon Buckles

## FEATURES



### SECURE FIT

With four attachment points, the Baseworker™ chinstrap provides a secure fit and helps to hold the helmet firmly in place even during vigorous movement.



### ADJUSTABILITY

The chinstrap is easy to adjust on the head. Size and anchorage point adjustment offer a tailored fit for different head sizes, increasing stability and comfort.



### COMPATIBILITY

Specially designed for use together, the Baseworker™ chinstrap is tested and certified in combination with JSP® EVO® helmets to ensure full compatibility.



### EN 397 COMPLIANT

Automatically releases under forces of 150-250N for safety in case the helmet or strap gets caught on something, in accordance with EN 397 requirements.



### QUICK RELEASE BUCKLE

The chinstrap features an ergonomic quick release buckle allowing it to be unfastened easily for fast removal of the helmet.



### EASY FITTING

Fitting the chinstrap is easy. Simply attach to the helmet shell, put the helmet on, then adjust the strap to a comfortably secure fit.

## RANGE

## DOWNLOADS

[Image Pack \(ZIP\)](#)

## HEAD ACCESSORIES



JSP Limited. Worsham Mill. Minster Lovell. Oxford OX29 0TA. England.

Tel: +44 (0)1993 826050 / Fax: +44 (0)1993 824411 / Email: [sales@jpsafety.com](mailto:sales@jpsafety.com) / Web: [www.jpsafety.com](http://www.jpsafety.com)

Do Not Publish without written permission from JSP Limited. Contact [copyright@jpsafety.com](mailto:copyright@jpsafety.com). Information correct in the United Kingdom at date of issue and may be subject to change. Any third-party machine and automated translations processed by users may have inaccuracies and should not be relied upon.

Page 2 of 2 / Issued 20 Feb 2026 / Copyright 2018 - 2026. JSP Limited. All Rights Reserved.

