

Force®10 Typhoon[™] Full Face Respirator

Large (F10-1030) / BPB003-204-000-UK



DESCRIPTION

Force®10 TyphoonTM is an extremely lightweight, easy to maintain full face mask with panoramic visor. With 3 available sizes (S,M,L) and the ability to fit PressToCheckTM filters, the user can feel reassured of an excellent fit.

OPTIONS

Large (F10-1030) (BPB003-204-000-UK) Medium (F10-1020) (BPB003-004-000-UK) Small (F10-1010) (BPB003-104-000-UK)

SAFETY STANDARDS

EN 136



JSP Limited. Worsham Mill. Minster Lovell. Oxford OX29 0TA. England.

Tel: +44 (0)1993 826050 / Fax: +44 (0)1993 824411 / Email: sales@jspsafety.com / Web: www.jspsafety.com

Do Not Publish without written permission from JSP Limited. Contact copyright@jspsafety.com. Information correct in the United Kingdom at date of issue and may be subject to change. Any third-party machine and automated translations processed by users may have inaccuracies and should not be relied upon.



SPECIFICATIONS

Classification Class 1



Exhalation Valve
Typhoon Valve



4 Point Harness adjustment system Yes



BSI Kitemark **Yes**

Latex free Yes



Product Weight 380g

FEATURES



Prescription RX Insert Lenses

The RX Modular Prescription Kit enables the use of corrective lenses with the Force®10 Typhoon[™] respirator, preventing traditional prescription spectacles interrupting the face seal and compromising protection.



Typhoon[™] Valve

Low resistance exhalation valve for easy breathing, with stable mask configuration. Made from silicone it performs well at very low temperatures.



Available in 3 Sizes

Available in Small, Medium and Large to provide an even better fit to a wider range of face sizes and shapes improving the seal and level of protection. A size guide is available for use with Force®8 & Force®10 Typhoon[™] masks.



PressToCheck[™] Compatible

The Force®10 Typhoon[™] is compatible with both JSP Classic filters and our PressToCheck[™] filters, which allow for Daily Face Fit Reassurance[™].



RANGE

Filter Compatibility

Fully compatible with PressToCheck[™] twin filter cartridges, providing daily face fit reassurance with the easiest way to check the seal each time the mask is donned. Fit it - Press it - Check it.

Usage **R**

Mask Design Over-Moulded Visor & Face Seal, Twin Filter with Orinasal

RX Insert Optional

Mask Material Thermoplastic Elastomer & Polycarbonate

Metal Free Yes



Effortless Maintenance

The Force®10 Typhoon[™] has been meticulously engineered to incorporate a small number of key components. Disassembly, cleaning and maintenance are effortless with replacement parts available.



Excellent Face Seal

Extensive research has been carried out by NIOSH (ISO16976-2) to distinguish the worlds 5 most common facial shapes. Using this research JSP have digitally optimised the ergonomics of the Force®10 Typhoon[™] face seal to maximise wearer compatibility.

Peel-off Visor

Replaceable peel-off visor protectors are available to prolong the life of the Force®10 Typhoon™.



Ultra Lightweight Comfort

Comfort is a key feature of this ultra lightweight mask, the web like structure of the harness cradles the users head – ensuring wearer comfort throughout the working day.





VIDEOS

youtu.be/QXur8s3R7DI



JSP Limited. Worsham Mill. Minster Lovell. Oxford OX29 0TA. England.

Tel: +44 (0)1993 826050 / Fax: +44 (0)1993 824411 / Email: sales@jspsafety.com / Web: www.jspsafety.com

Do Not Publish without written permission from JSP Limited. Contact copyright@jspsafety.com. Information correct in the United Kingdom at date of issue and may be subject to change. Any third-party machine and automated translations processed by users may have inaccuracies and should not be relied upon.

DOWNLOADS

- Image Pack (ZIP)
- doc-force-10-typhoon-full-face-mask.pdf (PDF)



JSP Limited. Worsham Mill. Minster Lovell. Oxford OX29 0TA. England.

Tel: +44 (0)1993 826050 / Fax: +44 (0)1993 824411 / Email: sales@jspsafety.com / Web: www.jspsafety.com

Do Not Publish without written permission from JSP Limited. Contact copyright@jspsafety.com. Information correct in the United Kingdom at date of issue and may be subject to change. Any third-party machine and automated translations processed by users may have inaccuracies and should not be relied upon.

